

Fitting instructions

Fitting procedure Zeno-Protect Super / Solution Clean-Off-Zone

It is recommended that the Zeno-Protect range of Clean-Off-Zones is adhered with a suitable adhesive. For recommended adhesives and procedures check with adhesive manufacturers. The subfloor must be dry, smooth and free of defects.

Fitting must be carried out in accordance with the instructions of the adhesive manufacturers.

Loose-lay is **not** recommended: the DDA (Disability Discrimination Act) states that surface laid rugs should not be used in public areas.

Fitting procedure Zeno-Protect Star

Protect Star is easily cut with a sharp knife. It can be laid in a matwell or on a hard, smooth surface.

Matwell – fitting

Unroll Protect Star on site and allow acclimatizing for approx. 8 hours. Cut the material approx. 2% oversize and use a blunt tool to push the Protect Star into the matwell. Protect Star can be butt jointed using underneath a flat pvc tape and coldweld paste to adhere the butt joint.

Note:

Zeno-Protect BV and their appointed representatives cannot be held responsible for the performance of adhesives. The information is a guide only.

Fitting (and supply) of our range of products is best carried out by a professional flooring contractor.